ThermTec



Thermal Imaging Scope IBEX SERIES User Manual App Store Google Play








Table of Contents

About This Manual	4	5.5.1 Taking photos/videos	17
Regulatory Information	5	5.5.2 Laser Ranging	17
1 Introduction	6	5.5.3 Pseudo Color Switch	18
1.1 Device Description	6	5.5.4 Target outline Mode	18
1.2 Features	7	5.5.5 Standby Mode	18
1.3 Detection Range	8	5.5.6 Contrast and Brightness Adjustment	18
1.4 Cautions	8	(shortcut menu)	
2 Packing list-IBEX	9	5.6 Entry of the Main Menu	19
3 Specification IBEX	10	5.7 Image Settings	21
4 Appearance	11	5.8 Settings	22
4.1 dimensions	11	5.9 Zeroing	29
4.2 Buttons and Operations	12	5.9.1 Manual Zeroing	30
5 Operation Guide	14	5.9.2 Ballistic Calculator	32
5.1 Battery Installation	14	5.10 Reticles	33
5.2 Power-on the Device	14	5.11 Blind Pixel	35
5.3 Main Menu	14	6 Network Connection	35
5.4 Lens Adjustment	15	6.1 App Download	35
5.4.1 Diopter Adjustment	15	6.2 Connection via Hotpot	36
5.4.2 Objective Lens Focusing	15	7 Firmware Upgrade	36
5.4.3 Digital Zoom	16	7.1 Upgrade via PC	36
5.4.4 Image mode	17	7.2 Upgrade via Mobile Application	37
5.5 Shortcut Menu	17		

About This Manual

COPYRIGHT©2025 ThermTecTechnologyCo.,Ltd.ALL RIGHTS RESERVED.

Any and all information, including, among others, wordings, pictures, graphs are the properties of Therm-Tec Technology Co., Ltd. or its subsidiaries (hereinafter referred to as "ThermTec"). This user manual (hereinafter referred to be "the Manual") cannot be reproduced, changed, translated, or distributed, partially or wholly, by any means, without the prior written permission of ThermTec. Unless otherwise stipulated, ThermTec does not make any warranties, guarantees or representations, express or implied, regarding to the Manual.

This Manual is applicable to Thermal Imaging Scope.

The Manual includes instructions for using and managing the product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons.

Regulatory Information

These clauses apply only to the products bearing the corresponding mark or information.



This product and, if applicable, the supplied accessories are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the Radio Equipment Directive 2014/53/EU, the EMC Directive 2014/30/EU, the ROHS Directive 2011/65/EU.



This product and - if applicable - the supplied accessories too are marked with "UKCA" and comply therefore with the following directives: Radio Equipment Regulations 2017, Electromagnetic Compatibility Regulations 2016, Electrical Equipment (Safety) Regulations 2016, the Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012.



This product and - if applicable - the supplied accessories too are marked with "RoHS" and comply therefore the requirements of Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment ("RoHS recast" or "RoHS 2").



2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.



Directive 2006/66/EC and its amendment 2013/56/EU (Battery Directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see:www.recyclethis.info.

1 Introduction

1.1 Device Description

The IBEX Series Thermal Imaging Scope delivers exceptional performance: it has a high-sensitivity detector (less than 18mK, up to 384×288 resolution) for sharp imaging in tough conditions, a built-in LRF module for accurate ranging up to 1000m, and a 1600×1200 OLED display for long-distance views—even in harsh environments, low visibility, or total darkness. It lets users see through target-obscuring obstacles (e.g., light foliage) and calculate target distance precisely, connects seamlessly to a mobile app for live viewing and sharing, and with its user-friendly design (intuitive controls, simple interface), it's ideal for beginners too.

IBEX Series thermal imaging scope facilitates applications in a wide range of fields, including observation, night hunting, rescue operations, hiking, traveling, etc.





1.2 Features

18 mK Sharp Clarity

With NETD < 18 mK, a 50 Hz refresh rate, and 1600x1200 0.5" AMOLED display, IBEX captures subtle temperature differences, cosistently delivering smooth and detailed imagery.

Integrated LRF Design

The LRF-integrated all-in-one streamlined design enhances visual appeal and structural strength while maintaining excellent optical performance, offering laser ranging capability up to 1000m.

Super Imaging Detail

Combining optical magnification with continuous digital zoom up to 14.8x, empowered by super-resolution algorithm, it delivers ultra-detailed images without any loss of quality.

Replaceable & Durable Batteries

Two replaceable 18650 batteries ensure durable operation, with each providing up to 6 hours of continuous use.

Central Turret Focus System

The unique central turret focus system makes it easier and more comfortable to focus compared to traditional focusing design.

Consistently Clear & Stable Image

ThermTec Al calibration reduces shutter frequency, minimizes image freezing and ensures stable and consistent images over changing environments.

Accurate Long-Range Shooting


The ballistic calculator optimizes the aiming process of distant targets with automatic angle compensation analysis and custom impact reticles.

Intuitive Operation Design

The scratch-resistant aluminum alloy construction makes it lightweight and compact, weighing just 770g. Tactile buttons and an independent lens cover enhance operational comfort.

1.3 Detection Range

The illustration below shows the comparative range performance of the device with different lens configurations. The data is based on detecting a car of 4m, a man of 1.8m tall, a wild boar of 0.7m tall, a wolf of 0.5m tall, a rabbit of 0.3m tall and a bird of 0.2m tall.



1.4 Cautions



CAUTION



Avoid hard objects.



Do not aim the lens directly at the sun or high-temperature light sources.



Do not use the device in extremely cold or hot environment.



Charge the battery once every three months when it is not used for a long period of time.



Do not irradiate the laser indicator of the device to human eyes.



Never disassemble or modify the device on your own.

Packing List – IBEX




SpecificationsIBEX

Model	IBEX335L
	Microbolometer
Туре	Uncooled
Resolution	384×288
Pixel pitch	12μm
NETD	<18mK
Spectral range	8-14μm
Frame rate	50Hz
Detection Range	1800m
	Optics
Objective lens	35mm
Field of view	7.5°×5.7°
m@100m	13.2×9.9
Magnification	3.7X
Digital zoom	1.0-4.0X
Eye relief	50mm
Exit pupil	6mm
Diopter	±5D
	Aiming Reticle
Reticle	7
Reticle color	6
	Display
Туре	AMOLED
Resolution	1600×1200
Display size	0.5 inch
Color palette	6

	Function	1		
Max. recoil power on r	ifled weapon	6000J		
Mounting brackets	on weapon	Standard 30mm rings		
RAV		Yes		
TASS		Yes		
Audio Record	ding	Yes		
Manual zero	ing	Yes		
Zeroing prof		6		
Freeze Zero	ing	Yes		
Picture-in-pic	ture	Yes		
LRF		1000m		
Ballistic Calcu	lator	Yes		
Image calibra	tion	Manual/Auto		
	Video Reco	rder		
Photo/video playback		Yes		
Inbuilt memory		64GB		
	Interfac			
Type C	Data	transfer, Battery charge		
Hotspot		Yes		
	Battery			
Battery type	R	eplaceable, 1*18650		
Battery life		6h		
0	Environm			
Operating temperature	-20- +50°C			
IP rating	_	IP67		
Weight, g		770±5(w/o Battery)		
Size, mm		344(L)×86(W)×70(H)		
	Accessori			
External cable		USB data cable eyeshade and etc.		
Other accessory	Other accessory			

Appearance 4.1 Dimensions




IBEX 335L reference only

4.2 Buttons and Operations

	Before the entry of main menu								
lcon	Annotation	Rotation	Short Press	Long Press	Double Press				
0	Power button	/	Standby Mode	ON/OFF	Image calibration				
	Laser Rangefinder	/	/ LRF Turn On/OFF		Color Palettes Shift				
	Capture/Record	/	Take photos	Record	PIP on/off				
	Rotating knob A	Digital zoom/ Contrast/Brightness	Shortcut menu	Entry/Exit shortcut or main menu	1				
	Rotating knob B	Focus	1	1	1				

After the Entry of Main Menu						
Rotating Knob A	Rotation	Short Press	Long Press	Double Press		
Knob A	Selection switching	ок	Exit	1		

4.2 Buttons and Operations



١٥.	Comments
1	Laser rangefinder module
2	Battery slot with 18650
3	Focusing knob
4	Digital zoom knob
5	Photo/Record button
6	Laser rangefinder turn On/Off button
7	Power On/Off button
8	USB interface
9	Diopter adjustment
10	Rubber eyeshade

5 Operation Guide

5.1 Battery Installation

IBEX Series with one battery can be installed in the lateral battery holder, and there is negative polarity of battery that must be towards outside. Please refer to the following figure for the installation of the replaceable battery.



Note:

IBEX can be charged by the Type-c immediately.

5.2 Power-on the Device



Power button

Users could long press the power button to power on/off the device.

In addition, it is available to short press the power button to enter device's standby mode to keep the screen locked.

5.3 Main Menu

Long press the digital zoom knob to enter the main menu. After the entry of Main Menu, short press the button for the operation of "confirmation", and long press the button for the operation of "Exit". Rotating the knob is to move the cursor.





Main Menu

5.4 Lens Adjustment

5.4.1Diopter Adjustment

Slowly rotate the diopter adjustment ring to adjust the position of diopter level to optimize the image sharpness on the OLED display.



5.4.2 Objective Lens Focusing

Objective lens rotating knob is on the top of the middle, please manually adjust the focusing knob when necessary.

Aim at the target and rotate focusing knob until the image of object is clear.



Both clockwise and anticlockwise rotation of the foucsing knob are allowed.



Before



After(reference only)

5.4.3 Digital Zoom

On the main interface, rotating the digital zoom knob anticlockwise can increase magnification up to $4.0\times$, and vise versa.





5.4.4 Image mode

Here includes two kinds of image modes which are respectively Forest and Rainy could be selected by user.



5.5 Shortcut Menu 5.5.1 Taking photos/videos



Take photos - short press the Capture/Record button; Take videos - long press the Capture/Record button.

5.5.2 Laser Ranging



Laser Rangefinder - short press the Laser Range- finder button to turn on/off the laser rangefinder.

5.5.3 Pseudo Color Switch



Pseudo color switch-double press the Laser rangefinder button to switch the pseudo colors.

5.5.4 Target Outline Mode





Target Outline Mode - long press the Rangefinder button to turn on/off the Outline Mode of the target.

5.5.5 Standby Mode



Standby Mode - short press the Power button

5.5.6 Contrast and Brightness Adjustment (shortcut menu)







- 1.Short press the middle of digital zoom knob to enter the Contrast or Brightness adjustment interface in the observing mode.
- 2.Rotate the knob to adjust value of contrast or brightness level.
- 3.Long press the knob to exit the shortcut menu.

5.6 Entry of the Main Menu

Long press the digital zoom knob to enter the main menu. After the entry of Main Menu, short press the knob for the operation of "Confirmation", and long press the knob for the operation of "Exit". Rotating the knob is the operation of moving the cursor.



Color Plate

Noted: Above picture is just for reference, please find it based on practice.


Color Palettes



5.7 Image Settings

There are four sub-menus for image settings, which are "Brightness" "Contrast" "Sharpness" and "Denoise". Short press the digital zoom knob these sub-menus under the image menu, then rotate the knob to adjust related image parameter.


	Image Setting Sub-menus					
Brightness ∙∴	1-10	Adjust the image brightness to make the image brighter. The recommended value is 5.				
Contrast	1-10	Adjust the image contrast to make the object more prominent in the image. The recommended value is 5.				



5.8 Settings

Short press the digital zoom knob to enter the sub-menus of Settings, and rotate the digital zoom knob to adjust the parameters accordingly.


		Sub-menus of Settings
Zeroing profiles	A-F	There are six zeroing profiles from "A-F" in the file folder, which contain the distance, type of bullet, and the coordinates of the crosshairs after zeroing.
PIP		The image is enlarged by 2x as centered by the crosshairs. Picture-in-picture occupies 10% of the entire image.





Files	Record	Open the sub-menu of Video, and rotate the knob to select the videos.	Setting	Correc- tion	The image correction mode could be set to Auto or Manual.
Setting OO OO	Audio	Turn on/off audio function to record the related voice in the video before user takes the recording.		Tracking	Turn on heat tracking function to mark the hottest target on the screen in real time.

Setting	RAV	After turning on the RAV, the scope will record videos before, during and after your shot. The threshold can be modified manually for different weapons and ammunitions.	Setting	OLED (bright- ness)	The bright level of OLED can be adjusted on this sub-menu.
000	Blind Pixel	User can operate blind spot replaced function when pups up blindness.	80	OLED (color)	The background color of the OLED can be selected on this sub-menu.

Setting OO OO	OLED (mode)			Smooth	Smooth: The speed of zooming more seamless. Rapid: Integer zooming, suitable for fast moving target tracking.
	Logo	Show or hide the Logo in the captured images or videos.	Setting 00 00	TASS	On:The current digital zooming can get back to minimum zooming magnification automatically after the shooting, exactly TASS depends on activate rav function as the priority. TASS means that user can be always more rapid locking the target instead
		Logo			of traditional knob via the manual.







5.9 Zeroing

Enter the Main Menu, rotate the digital zoom knob to move curror to " λ " and short press the knob to enter the sub-menu of Zeroing.

- ①Rotation and short pressing knob for selecting Zeroing menu.
- ② Short press the knob one more time. Rotate and short press the knob to select and confirm the zeroing distance (e.g. 25m or 35m).
- ③After that, move the cursor and short press the knob to enter the Gun Type screen.

Short press the knob to add the Gun Type (customizable; press "Enter" on keyboard to add the Gun Type). Long press the rotary knob to return to the previous screen.



5.9 ①



5.9 ②



5.9 3

Notes:

It is recommended to do Zeroing at a temperature that close to the scope's operating temperature.

5.9.1 Manual Zeroing


- ① Rotate the digital zoom knob anticlockwise, and move the cursor to finding manual zeroing menu.
- ② Short press the digital zoom knob to enter the Manual Zeroing screen, confirm the zeroing distance, and short press "OK" to enter the next step.
- ③ After your first shooting is completed, align the reticle with point of aiming, and rotate the knob to turn on the Freeze function. ※ After that, A screenshot will be taken. (The Freeze function allows you to freely scope without losing reticle placement on the point move or manipulate the of aim during adjustments.)
- Rotate the digital zoom knob to change the magnification if necessary, which helps to improve the accuracy of zeroing.
- 5 Adjust the coordinates (X, Y) of the reticle by rotating the digital zoom knob, and move the reticle from the original position to the bullet hole position manually. After pressing the Save button, the values of X and Y will change according to the magnification.
- e.g. X: -20mm, Y: -20mm (1x); X: -10mm, Y: -10mm (2x): X: -4mm, Y: -4mm (5x).



5.9.1 ①



5.9.1 (2)





5.9.1 (5)

Notice: About the steps of zeroing with number $3 \cdot 5$ for reference only.



5.9.1

Notes:

1.The changes will always be saved based on your last calibration, e.g. the first saved coordinate is (-20mm, 35mm) in Profile A and you may want a tiny change like (-5mm,5mm), so the device finally displays (-25mm, 40mm). If you put the same weapon name and the same distance, it takes data from the previous profile.

2.Please get back to the main menu to choose other profiles if you would like to save new data for another gun. It is suggested to save the subsequent changes where you first time saved for the same gun. It is not recommended to save a change in Profile A firstly then another change saved in Profile B or C.

5.9.2 Ballistic Calculator

- ① Rotate the digital zoom knob to move the cursor to the menu of ballistic calculator, then short press the knob to the third-level menu.
- ② Rotate the digital zoom knob again to move the cursor to Setting, and short press the digital zoom knob. There you can configure the parameters as your need, including Scope Ht, Wind Velocity, Bullet Wt, Muzzle Velocity, BC, Wind Direction, Temperature, and Pressure.
- ③ When any parameter is selected for modification, the cursor would automatically move to the keyboard section at the right side of the screen.
- Click Enter and the cursor will return to left side of the screen.
- ⑤ Move the cursor and click the Back section to return to the previous screen.





5.9.2 ①

5.9.2 (2)

Auxiliary line of trajectory

- Users first need to move the cursor to "ON" to turn on the ballistic calculator function.
- After activation, here are totally icon will appear in the center of the screen. When the icon doesn't match the coordinates after zeroing, users should aim it at the certain target, then fill in the actual parameters into the "Setting" interface.



Attention:

1.The indicating cursor types of ballistic calculator have four different styles, user can get it in the BC symbol menu.

- 2. Ballistic calculator function needs to be carried out after zeroing, otherwise there is no practical significance.
- 3. When ballistic calculator is turned on, the device will automatically switch to single ranging mode.

5.10 Reticles

Type ⊣ ≌	1-8	Rotate the digital zoom knob to select the type of reticles. There are 8 types of reticles set for selection.	Bright- ness -☆-	3	Rotate the knob to select the brightness of reticles. There are 3 degrees of brightness set for selection.
Color (**)	5 Colors	Rotate the knob to select the color of reticles. There are 5 options: Black, White, Red, Green, and Blue.	Dot [•]	5 Colors	Rotate the knob to adjust the color of the Dot. There are 3 options: White, Black, Red, Blue, and Green.

Rotate the knob to select the location of reticles. There are 2 options: "Move" and "Center". Move: Under 1x magnification, the FFP: The reticle changes as location of the reticle keeps the same zooming in; as the zeroing coordinates. The SFP: The reticle doesn't change reticle will return to the center as the zooming in. of the screen when image is zooming in. Center: When zeroing is finished, the screen will be slightly enlarged based on the zeroing coordinates. The reticle will return to the center of the screen. When zooming in or Locaout, the reticle will always enlarge at Move/ Mode tion the center of the screen FFP/SFP Center \otimes (O)

Reticle polarity reverse helps find and lock small target. (Only for Black & White Reverse)



Reversal ON/OFF

Notice: Totally three icons (crosshairs under the black & white,laser icon, ballistic calculation icon) can be automatical switching the color while enabling Reversal function.

5.11 Blind Pixel

There are three options (cancel, save and replace). Replace: the blind pixel on the screen can be replaced. When finished, long press the middle of the rotary knob to exit, figure shown as below.



6

Network Connection

6.1 App Download

Users could download our mobile APP named "ThermTEC Outdoor" in Apple Store and Google Play, or through the QR code shown on the packing box or user manual.









6.2 Connect via Hotspot

1) Turn on the device's Hotspot.



② Connect your mobile phone to device's Hotspot via WLAN. To input default password of device (1 to 8). ③ After successful connection, you can control devices via APP.

Notice: All devices are same password (1 to 8) when out of factory , which means, user can't set password type by manual operation.

7 Firmware Upgrade

7.1 Upgrade via PC

①Users could download corresponding upgrading package from our website. After that, connect your device to PC via Type-C cable, and copy the firmware to device's file folder.



7.1 ①

- ② Enter the Settings menu, and select Update, then there will be a pop-up window prompting "Program Updating".
- ③ When the update is completed, the device will automatically restart.



7.1 (2)



7.1 (3)

7.2 Upgrade via Mobile Application

IBEX series thermal imaging sight could be interconnected with "interconnected with "ThermTec Outdoor" APP, which allows users to transfer files from device to smartphone or tablet via Hotspot, easily achieving remote control.

Users could refer to the following steps to realize device firmware upgrade via our mobile APP:

- ① Open the ThermTec Outdoor APP.
- ② Turn on the Hotspot of the device, and connect your mobile phone to device' Hotspot.
- 3 Select Update on the menu options.
- It will take a continuous period of time for downloading and upgrading if a new version of firmware is detected, so please be patient.
- ⑤ Once the upgrade is complete, the device will reboot automatically.









ThermTec Technology Co., Ltd.

Email: info@thermeyetec.com Web: www.thermeyetec.com